



# MEASURING GUIDE

## How to measure for your leg cover: *Above Knee*

- **Length:** measure from just below the knee joint (A) to top of the foot shell (B). Take away 2cm, to leave a recommended gap between top of foot shell and bottom of cover. This gives the **Length**.
- **Circumference:** measure the circumference around the widest part of the sound limb or leg socket.

## How to measure for your leg cover: *Below Knee*

- **Length:** measure from lowest dip of the socket (A) to top of the foot shell (B). Take away 2cm, to leave a recommended gap between top of foot shell and bottom of cover. This gives the **Length**.
- **Circumference:** measure the circumference around the widest part of the sound limb or leg socket